

1 The orientation of the mounting plate is chosen depending on the RAM Cradle.



2 Remove the spacer ring before attaching the clamps to a 1 1/4 Inch bar.

1 Inch
25,4 mm



1 1/4 Inch
31,8 mm

